



## T Connector Assembly Instruction

1. Set up the 3pcs fixtures in T type.




2. Enlarged photo in red circle part.





3. Steps of Shorten cable length

a. Loosen the cable gland of the power cord.




b. Pull out the cable and strip the black outer insulation. And clean talcum powder and remove cotton thread. It's too hard to push into the cable gland when the black outer insulation is too long


c. Push the wire back into the cable gland. Don't lock the cable gland.




4. Put the 8pcs of #3 screws into the light module board chute.




5. Align 3pcs fixtures into T-shape.




6. Put 1pcs type I interlock and 2pcs L type interlocks in the screws, and confirm that it is necessary to move the wire harness of the lamp wire to avoid interfering with the interlock.




7. Lock 8pcs nuts on the I type interlock and L type interlock, and use the level to confirm the flatness of the fixture.




8. Loosen the cable gland of the power cord. Insert the T connector to link three fixtures and confirm the position of wire to avoid interfering with the covers before tightening the cable gland.



9. Put on the interconnection Cover "VLA-C-T".



10. Put on the interconnection Cover "VLA-C-I-2".



11. T Connect assembly completed. And power on the fixtures after all fixtures are installed.

